


HOW TO MAKE YOUR FIRST PICTURE A SUCCESS

It will be easier if you make your first color picture indoors with flash.
For each step we'll tell you the page in the instruction book that shows you what to do.

1. Load the camera with color film. Close and lock the back, then pull out the safety cover (p. 6-7).



Push pack down into camera.

2. Insert a flashcube and turn it clockwise as far as it will go (p. 10).



Insert flashcube at 45 degree angle.

3. Check that the Film Selector and the Lighten/Darken control are set as shown. If not, see p. 10.



Set Film Selector at 75.




Leave L/D control at Normal.

4. Turn the lens to the 5 ft. mark (p. 11).



Set lens at 5 ft.

5. Place your subject a few feet from a light colored or white wall and stand about 5 ft. from your subject (p. 11).




Find a good background.

6. Aim and shoot (p. 11).




Place Color Spot over person's face.

7. Set the timer to 60 seconds.




Turn pointer clockwise.

8. Pull the tabs to develop the picture, start the timer, and when the buzzing stops, separate your picture (p. 12-14).



Pull white tab, then yellow tab.



Lift print quickly.

Now, please stop and read the instruction book from cover to cover.